

FIG. 1




FIG. 2




FIG. 3




FIG. 4A




FIG. 4B




FIG. 5A




FIG. 5B




FIG. 6




FIG. 7




FIG. 8




FIG. 9




FIG. 10

SETTING SCREEN

STATE 2

PAGE DESIGNATION: 30-40

DOUBLE SIDED PRINTING: NO

SHORTER SIDE

LONGER SIDE

Nup: 2

4

8

36

37

38

39

40

FIG. 11

SETTING SCREEN

GROUP STATE 1

PRINTER NAME: PRINTER 1

SHEET SIZE: A4

B5

A3

LETTER

36

38

40



FIG. 12




FIG. 13A




FIG. 13B




FIG. 14




FIG. 15




FIG. 16B




FIG. 16A




FIG. 17

